

FITTING INSTRUCTIONS FOR EXPOSED WALL MOUNTED THERMOSTATIC BSM

- 1). Connect the offset cranked unions to the wall water supply and the thermostatic body to the wall unions. (when installing the water supplies make sure they are not installed too low as you will not achieve the correct shower head to bath clearance height. Recommended 900-1000mm above floor level.
- 2). Connect the short angled shower pipe to the BSM body
- 3). Connect the straight shower pipe and mark the wall securing bush position. Remove the straight shower pipe and mount the securing bush to the wall. Locate the straight pipe into the lower angled pipe and secure the pipe to the wall bush. Slacken off the pipe securing screw.
- 4). Connect the angled long shower pipe to the short straight shower pipe. Adjust and Secure.
- 5). Connect the shower head, hose and handset.

BOX CONTENTS

- a) Bath shower mixer body including wall mount unions. There is a low pressure aerator in this box if required.
- b) Short angled connector pipe with hose diverter fitted
- c) Short straight connector pipe.
- d) Small box containing wall connector bush.
- e) Long angled unboxed shower pipe
- f) Shower head
- g) Shower handset
- h) Shower hose